



# Safety Spectacles

## INSTRUCTIONS

## 08/2015

For:	Stock No.	Part No.	
	03109	SSP7UV	Smoked anti-mist and UV protection safety spectacles
	03110	SSP9UV	Smoked anti-mist and UV protection safety spectacles
	03111	SSP10UV	Smoked anti-mist and UV protection safety spectacles
	11969	SSP12UV	Safety spectacles with UV protection and flexible frame
	12037	SSP6	Clear anti-mist safety spectacles
	12049	SSP8	Clear anti-mist safety spectacles
	12057	SSP10	Clear UV protection safety spectacles
	12062	SSPY10	Yellow anti-mist UV protection safety spectacles
	12172	SSPFF11	Clear, flip-up anti-mist safety spectacles



## APPLICATION

This PC safety eye wear / wire mesh safety eyewear satisfies the requirements of the European Directive 89/686/CEE, regarding equipment for individual protection and is made according to the requirements of the standards EN166, EN1731.

### - Applications:

HC/ CHOB Safety Protectors are in accordance with the reference standards, the CE marking and the number of the EN standard. EN standards is compulsory with the various symbols of the using domain.

Speed particles symbols: F Low energy impact (45m/s)

If the F symbol is not the same for the lens and the frame, then the lowest level should be assigned to the complete eye protection. The letter T immediately after the impact letter allows a use for high speed particles at extremes of temperature. In the absence of the letter T, the protector must be used in ambient temperature.

Symbols for the optical class: 1 Continuous work

Standards by application type: EN166 (Safety Spectacles/Eye-protector)



## SAFETY SPECTACLE CARE

### - CLEANING AND DISINFECTION:

Product must be cleaned or disinfected with a product like soapy water, optical cleaning solution, or a solution very low in alcohol.

### - MAINTENANCE:

Like all other protective products, the life depends on the type of use, care and maintenance. If your frame is damaged, replace the entire article. We recommend that spectacles and goggles are kept in a suitable case when not in use. In every case, the product must be replaced after a period of two years.

### - WARNING:

Pitted scratched or damaged lenses must be replaced by original products. Under special circumstances, some people with extremely sensitive skin may suffer from allergies caused by some materials coming into contact with the skin. A protector worn over prescription spectacles can pass on the impact with a potential risk.

### - REPLACEMENT LENSES:

Make sure that the spare lenses are identical to the lenses of origin.

### - TRANSPORT:

The protector must be transported in its packing of origin.

### - STORAGE:

Store between 5° to 40°C; humidity less than 90%.