



12W/230V Fluorescent Magnifying Desk Lamp

Stock No.05718

Part No.DMAGL

The Draper Tools policy of continuous improvement determines the right to change specification without notice.

Stock no.	05718
Part no.	DMAGL
Rated voltage	230V~50Hz
Rated input	12W
Environment temperature	-20°C ~ 40°C
Humidity	≤ 95%
Lens viewing size	94mmØ
Magnification of lens	2x
Magnification of lens insert	4x



REPLACEMENT OF LAMP

- Switch off the magnifier lamp and take the plug out of the socket.
- Take off the transparent tube protection cover.
- Replace the broken tube with a new one.
- Put on the tube protection cover.



IMPORTANT FOR SAFE USE

- Indoor use only.
- Environment temperature -20°C ~ 40°C.
- Humidity: ≤ 95%.
- The plug must be taken out while repairing the magnifier lamp.
- Never disassemble the magnifier lamp unless you are a qualified electrician.
- If the external flexible cable or cord of the magnifier lamp is damaged, it should be replaced by a special cable or cord exclusive available from the manufacturer or its service agent.