

24 Hour Mechanical Timer

Stock No.44914
INSTRUCTIONS

Part No.MT3 09/2007



SPECIFICATION

The Draper Tools policy of continuous improvement determines the right to change specification without notice.

Stock No.

 Part No.
 MT3

 Rated input:
 240V~50Hz

 Max. output:
 3000W

 Capacity.
 13A resistive load

 Min. Temperature:
 0°C

 Max. Temperature:
 55°C



ACCURACY



PRECAUTIONS

- For indoor use only.
- Do not use with any appliance, which exceeds the capacity of the Timer.
- Always ensure that the plug of any appliance is fully inserted into the Timer.
- If you need to clean the Timer, remove from the mains and wipe with a dry cloth. Do not immerse in water or any liquid.
- Fan heaters and heaters with exposed elements should not be left unattended, and it is recommended that this type of appliances are not to be connected to timers.



SETTING THE ON/OFF PERIODS

Daily Plug-in Timer:

- This timer can set up to 24 On/Off commands a day.
- Using your finger, a pen or screwdriver pull up all the segments that correspond to the desired "Off" period. For the desired "On" period, make sure the segments are pushed down. Each segment represents 30 minutes.



24 Hour Mechanical Timer

Stock No.44914
INSTRUCTIONS

Part No.MT3 09/2007



SETTING THE TIME

Turn the dial clockwise until the triangular pointer is pointing at the actual time. Ensure that the switch on the side of the unit is set to the \bigcirc position.



MANUAL ON/OFF

The pre-set On/Off commands can be interrupted by using the manual override switch located on the side of the unit. When swiched to the position I, the connected appliance is switched on permanently.



CONNECTION

Once the desired On/Off periods and actual time are set, plug the Timer into the wall socket, and then the appliance's plug into the Timer. Ensure the wall socket and the appliance are on. The Timer will start to operate and switch on and off the appliance according to the pre-set On/Off commands.



DISPOSAL

- At the end of the machine's working life, or when it can no longer be repaired, ensure that it is disposed of according to national regulations.
- Contact your local authority for details of collection schemes in your area.
 In all circumstances:
 - Do not dispose of power tools with domestic waste.
 - Do not incinerate.
 - Do not abandon in the environment.
 - Do not dispose of WEEE* as unsorted municipal waste.



* Waste Electrical & Electronic Equipment.